



ACCESSORIES

All Weather and Carpet – Floor Mats

General Motors strongly recommends that you use only floor mats designed specifically for the model and model year of your vehicle, and that they are properly installed and secured.

1. Remove production floor mat. See Figure 1.
2. For mat with retainer holes proceed as follows:

Install the All Weather Floor Mat using the fasteners located on the floor. See Figure 3.

- **DO NOT** use a floor mat that is flipped over with the bottom-side up.
- **DO NOT** stack one floor mat over another floor mat. See Figure 2.
- Check the operation of the accelerator, brake, and clutch (if applicable) pedals to assure that the floor mat does not interfere with them. See Figure 3.

